

Theme: 9. Power train

Points	K	No	Question, answers	Graphic images
2		9/1.	<p>Which of the items listed below are components of the power train (transmission):</p> <p>the clutch and the transmission box</p> <p>the cardan drive</p> <p>the differential and axle shafts</p> <p>the steering mechanisms of the motor vehicle</p>	
2		9/2.	<p>The clutch is a component of:</p> <p>the steering mechanisms of the motor vehicle</p> <p>the power train (transmission) of the motor vehicle</p> <p>the vehicle chassis</p> <p>the suspension of the vehicle</p>	
2		9/3.	<p>The function of the clutch is:</p> <p>to engage the internal combustion engine to the cardan drive</p> <p>to engage the engine to the transmission and to disengage the engine from the transmission for a short period of time</p> <p>to engage the components of the transmission to the chassis</p>	
2		9/4.	<p>When the engine is running and the clutch is engaged, the clutch is actuated by:</p> <p>the vehicle starter</p> <p>the flywheel of the internal combustion engine</p> <p>by the vehicle generator</p>	
2		9/5.	<p>When the clutch pedal is pressed:</p> <p>the clutch is disengaged and the power train is uncoupled</p> <p>the clutch is disengaged and the power train is coupled</p> <p>the clutch is engaged</p>	
2		9/6.	<p>When the clutch pedal is released:</p> <p>the clutch is engaged and the power train is uncoupled</p> <p>the clutch is disengaged and the power train is uncoupled</p> <p>the clutch is engaged and the power train is coupled</p>	
2		9/7.	<p>The transmission box is a component (unit) of:</p> <p>the steering mechanisms of the vehicle</p> <p>the power train (transmission) of the vehicle</p> <p>the vehicle chassis</p> <p>the steering system</p>	
2		9/8.	<p>The function of the transmission box is:</p> <p>to change the transferred torque</p> <p>only to couple the internal combustion engine to the transmission</p> <p>to secure the turning of the front wheels</p>	
2		9/9.	<p>When the engine is running and the clutch is engaged, the transmission box is directly driven by:</p> <p>the crank shaft of the internal combustion engine</p> <p>the cardan drive</p> <p>the clutch</p>	

2		9/10.	<p>The gear ratio of the transmission box is determined by:</p> <p>the total number of gears of the transmission box</p> <p>the number of direct gears</p> <p>a neutral position, 1 (one), is added to the total number of gears of the transmission box</p>	
2		9/11.	<p>The cardan drive is a component of:</p> <p>the steering mechanisms of the vehicle</p> <p>the power train (the transmission) of the vehicle</p> <p>the transmission box</p> <p>the steering system</p>	
2		9/12.	<p>The function of the cardan drive is:</p> <p>to transfer torque from the clutch to the main transmission</p> <p>to transfer torque from the transmission box to the main transmission at a variable angle and varying distance between them</p> <p>to transfer torque from the transmission box to the wheels</p>	
2		9/13.	<p>The differential is a component of:</p> <p>the main transmission</p> <p>the power train (transmission) of the vehicle</p> <p>the steering mechanisms of the vehicle</p>	
2		9/14.	<p>The function of the differential is:</p> <p>to distribute the speed of rotation between the driving wheels depending on the specific driving conditions (driving in a turn)</p> <p>to change the direction of torque transfer at an angle of 90 degrees from the cardan drive to the driving wheels</p> <p>to amplify the torque transferred by the cardan drive to the driving wheels by changing of its direction and transferring it at an angle of 90 degrees</p>	
2		9/15.	<p>The differential may be located:</p> <p>in the vehicle suspension</p> <p>in the casing of the driving axle</p> <p>in the casing of the transmission box</p>	
2		9/16.	<p>The function of the main transmission is:</p> <p>only to reduce the torque transferred from the cardan drive to the driving wheels by changing its direction</p> <p>only to change the direction of the torque transferred from the cardan drive to the driving wheels</p> <p>to amplify the torque transferred from the cardan drive to the driving wheels by changing its direction</p>	
2		9/17.	<p>The axle shafts are components of:</p> <p>the wheels of the vehicle</p> <p>the power train (the transmission) of the vehicle</p> <p>the steering axle of the vehicle</p> <p>the vehicle suspension</p>	
2		9/18.	<p>The function of the axle shafts is:</p> <p>only to transfer torque from the main transmission to the driving wheels</p> <p>to transfer torque from the differential to the driving wheels and vice versa</p>	

2		9/19.	<p>The clutch is engaged by:</p> <p>smoothly releasing the clutch pedal</p> <p>smoothly pressing the clutch pedal</p> <p>abruptly releasing the clutch pedal</p> <p>abruptly pressing the clutch pedal</p>	
2		9/20.	<p>The clutch is disengaged by:</p> <p>smoothly pressing the clutch pedal</p> <p>quickly releasing the clutch pedal</p> <p>moderately quick pressing the clutch pedal to the end</p>	
2		9/21.	<p>Wearing out of the friction plate of the clutch is detected by:</p> <p>the abrupt increase of the vehicle speed when first gear is engaged</p> <p>no change in the speed of the vehicle when the revolutions of the engine are abruptly increased</p> <p>the abrupt increase of the vehicle speed when direct gear is engaged</p>	
2		9/22.	<p>Wearing out of the friction plate of the clutch:</p> <p>causes the increase of the free play of the clutch pedal</p> <p>does not affect the free play of the clutch pedal</p> <p>results in decreasing the free play of the clutch pedal</p>	
2		9/23.	<p>The “sliding” of the clutch plates is an indication of:</p> <p>large free play of the clutch pedal</p> <p>small free play of the clutch pedal</p> <p>normal free play of the clutch pedal</p>	
2		9/24.	<p>The free play of the clutch pedal is adjusted:</p> <p>every day</p> <p>twice a year, during the seasonal technical maintenance</p> <p>whenever necessary</p>	Correct – incorrect
2		9/25.	<p>Checking the level of fluid in the clutch tank is a compulsory operation:</p> <p>for all clutch types</p> <p>only for truck clutches</p> <p>for hydraulically actuated clutches</p>	
2		9/26.	<p>When the level of the fluid in the hydraulic cylinder tank of a hydraulically actuated clutch is reduced:</p> <p>water is added</p> <p>the same type of fluid is added</p> <p>ethyl alcohol may be added</p> <p>any kind of technical-purpose fluid may be added</p>	
2		9/27.	<p>When changing the fluid of a hydraulically actuated clutch:</p> <p>the components of the hydraulic mechanism are washed with water</p> <p>the components of the hydraulic mechanism are washed with ethyl alcohol</p>	

2		9/28.	<p>The daily technical maintenance of a hydraulically actuated clutch requires:</p> <p>grease lubrication</p> <p>inspection for leaks</p> <p>adding fluid when necessary</p> <p>adjustment</p>	
2		9/29.	<p>The emergence of a metallic scratching noise and increased temperature of the transmission box may be caused by:</p> <p>Wearing out of the gear wheels of the transmission box</p> <p>Wearing out of the ball sockets of the gear lever</p> <p>no oil or the use of oil with inappropriate quality</p>	
2		9/30.	<p>Worn out or deformed gaskets of the transmission box may cause:</p> <p>arbitrary disengagement of gears</p> <p>arbitrary engagement of the transmission box gears</p> <p>oil leak from the transmission box</p>	
2		9/31.	<p>The type of oil in the transmission box and the period of oil change is determined by:</p> <p>the driver, depending on road conditions</p> <p>the driver, depending on weather conditions</p> <p>the vehicle manufacturer</p>	
2		9/32.	<p>When the level of the oil in the transmission box is reduced:</p> <p>add oil of the type used in the engine</p> <p>replace the oil</p> <p>add the same type of oil</p>	
2		9/33.	<p>The oil in the transmission box is changed:</p> <p>while the engine is running, the clutch engaged and with a neutral position of the gear lever</p> <p>while the engine is running and with the clutch disengaged</p> <p>while the engine is off</p>	
2		9/34.	<p>The type of oil in the casing of the steering axle and the period of oil change is determined by:</p> <p>the driver, depending on weather conditions</p> <p>the vehicle manufacturer</p> <p>the driver, depending on road conditions</p>	
2		9/35.	<p>The quantity of oil in the casing of the steering axle must be:</p> <p>sufficient to fill the whole capacity of the casing</p> <p>not less than one litre</p> <p>up to the level of the control plug</p>	
2		9/36.	<p>The oil in the steering axle casing is changed:</p> <p>immediately before departure of the vehicle</p> <p>immediately after the vehicle is stopped</p> <p>according to the assessment and free time of the driver</p>	