







**Theme: 5. Basic safety rules**

Poi nts	K	No	Question, answers	Graphic images
2		5/1.	<p><b>Three identical orange lights on the driver's cab of a motor vehicle are used to mark:</b></p> <p>trucks with length above 7 m road vehicles carrying a load, which might cause pollution to the environment</p> <p>a motor vehicle towing one or more trailers</p>	
2		5/2.	<p><b>When passing by a road vehicle marked by three identical orange lights mounted on the driver's cab of the towing motor vehicle, the following would represent a danger:</b></p> <p>the possibility for a lateral deviation of the trailers the possibility of a load falling on the driveway a load, which might cause pollution to the environment</p>	
2		5/3.	<p><b>When a "tractor-trailer" combination is stopping, there is a probability for "folding" in case:</b></p> <p>the braking system of the trailer is engaged earlier than the braking system of the tractor</p> <p>when the braking system of the trailer is engaged later than the braking system of the tractor</p>	
2		5/4.	<p><b>In case the towing motor vehicle is equipped with an anti-lock braking system, but the trailer is not:</b></p> <p>a danger of "folding" of the combination of vehicles in case of emergency braking (the trailer will start pushing the tractor) exists the trailer will pull the tractor back while braking no danger exists as the trailer always stops earlier than the tractor</p>	
2		5/5.	<p><b>While coupling or uncoupling a trailer:</b></p> <p>there must be no load in the trailer the trailer must be secured against movement the emergency lights must be switched on</p>	
2		5/6.	<p><b>Which of the air compressor hoses must be disconnected first when uncoupling the trailer?</b></p> <p>the "feeding" hose, as in the reverse order the brakes of the trailer will be temporarily released the "brakes control" hose the sequence of disconnecting the air compressor hoses is of no importance</p>	
2		5/7.	<p><b>A trailer will be coupled to a truck more quickly when:</b></p> <p>a higher reverse gear is engaged a person is asked to assist in directing the vehicle first the parking brake of the trailer is released</p>	
2		5/8.	<p><b>When coupling the trailer, the person assisting in directing the vehicle must be standing:</b></p> <p>at the back right-hand side of the vehicle at the back left-hand side of the vehicle in the middle, at the back of the vehicle</p>	

2		5/9.	<p><b>If the driver stops seeing in the rear-view mirror the person assisting in directing the vehicle while driving backwards for the purpose of coupling a trailer to a vehicle, the driver must:</b></p> <p>give a sound signal and continue with the manoeuvre</p> <p><b>stop immediately</b></p> <p>switch on the emergency lights and continue with the manoeuvre</p>	
2		5/10.	<p><b>When coupling a trailer, the person assisting in directing the vehicle must be standing in the middle, at the back of the vehicle.</b></p> <p><b>incorrect</b></p> <p>correct</p>	
2		5/11.	<p><b>Is it allowed to carry people in a trailer towed by a truck?</b></p> <p>yes, if the people are stevedores</p> <p><b>no</b></p>	
2		5/12.	<p><b>While driving backwards, the driver of a combination of road vehicles must constantly monitor the road behind the vehicle, and if this is impossible, the driver must ask a person to signal in case of dangers.</b></p> <p><b>correct</b></p> <p>incorrect</p>	
2		5/13.	<p><b>Where must the driver be when loading or unloading is made by crane?</b></p> <p>in the tractor cab</p> <p><b>at a safe place outside the road vehicle</b></p> <p>it does not matter</p>	
2		5/14.	<p><b>In case of no other restrictions, the driver of a “C+E” category motor vehicle must not exceed, while driving outside a populated locality, a speed of:</b></p> <p>60 km/h</p> <p><b>70 km/h</b></p> <p>80 km/h</p>	
2		5/15.	<p><b>In case of no other restrictions, the driver of a combination of road vehicles of “C+E” category must not exceed, while driving on a highway, a speed of:</b></p> <p><b>100 km/h</b></p> <p>110 km/h</p> <p>120 km/h</p>	
2		5/16.	<p><b>In case of no other restrictions, the driver of a “C+E” category motor vehicle must not exceed, while driving in a populated locality, a speed of:</b></p> <p>60 km/h</p> <p><b>50 km/h</b></p> <p>40 km/h</p>	
2		5/17.	<p><b>In case of no other restrictions, the driver of a combination of road vehicles of “D+E” category must not exceed, while driving on a highway, a speed of:</b></p> <p>90 km/h</p> <p><b>100 km/h</b></p> <p>110 km/h</p>	

2		5/18.	<p><b>In case of no other restrictions, the driver of a “D+E” category motor vehicle must not exceed, while driving in a populated locality, a speed of:</b></p> <p>40 km/h  <b>50 km/h</b>  60 km/h</p>	
2		5/19.	<p><b>In case of no other restrictions, the driver of a “D+E” category motor vehicle must not exceed, while driving outside a populated locality, a speed of:</b></p> <p>60 km/h  <b>70 km/h</b>  80 km/h</p>	
2		5/20.	<p><b>In case of movement of a combination of road vehicles, the towing motor vehicle must be equipped with at least:</b></p> <p>one rear-view mirror  <b>two rear-view mirrors</b>  three rear-view mirrors</p>	
2		5/21.	<p><b>Is it allowed to tow a trailer without a registration plate?</b></p> <p>yes, in case the trailer has a maximum permissible mass of up to 750 kg  <b>no</b>  no, with the exception of the cases when transport is performed at a distance of less than 50 km</p>	
2		5/22.	<p><b>What measures must be taken in case you detect a failure in the coupling device of a combination of vehicles while driving?</b></p> <p><b>remain stationary until the failure is removed</b>  may proceed at a lower speed to the nearest service station</p>	
2		5/23.	<p><b>Is it allowed to couple more than one trailer to a vehicle?</b></p> <p><b>yes</b>  no</p>	
2		5/24.	<p><b>This identification sign is used to mark:</b></p> <p><b>trailers, including semi-trailers</b>  only semi-trailers  all trailers with the exception of semi-trailers</p>	
2		5/25.	<p><b>This identification sign is used to mark:</b></p> <p><b>trailers, including semi-trailers</b>  only semi-trailers  all trailers with the exception of semi-trailers</p>	
2		5/26.	<p><b>This identification sign is used to mark:</b></p> <p><b>trailers, including semi-trailers</b>  only semi-trailers  all trailers with the exception of semi-trailers</p>	
2		5/27.	<p><b>This identification sign is used to mark:</b></p> <p><b>trailers, including semi-trailers</b>  only semi-trailers  all trailers with the exception of semi-trailers</p>	

2		5/28.	<p><b>This road sign forbids:</b>  the entry of motor vehicles with trailers, with the exception of semi-trailers and one-axle trailers</p>	
		5/29.	<p><b>Is it allowed for a vehicle towing a one-axle trailer to enter after this road sign?</b>  yes  no</p>	
		5/30.	<p><b>This road sign forbids:</b>  the entry of motor vehicles with trailers, with the exception of semi-trailers and single one-axle trailers</p>	